




FRAME AND CONSOLE PARTS

For Model: DU920QWDB0

UNDERCOUNTER
DISHWASHER




1	3375291	Console (Includes Item 2)
2	3374803	Insert, Console
3	3375556	Control, Electronic
4	3376359	Fuse, Thermal
5	3374778	Switch, Display
7	304231	Screw
8	3374711	Door Frame (Includes Item 27)
9	3368953	Bolt, Latch
10	3369457	Lever, Latch
11	3369325	Switch, (2)
12	3368955	Pin, Switch (2)
13	3375572	Harness and Protector
14	3376405	Elbow, Harness
15	3400803	Screw
16	3375473	Cover Timer
17	3374501	Motor, Dual
18	3374777	Door, Sound Absorber
19	3369516	*Panel, Front (Almond/Black)
20	3374010	Retainer, Panel
23	3376186	Trim (2)
26	3373234	Bearing, Spring (2)
27	3374716	Channel, Retainer (Also Order Item 20)

*Refer To Dishwasher Replacement Panel Parts List No. 675345.

INNER DOOR PARTS

For Model: DU920QWDB0

Black




1	3371481	Inner Door (Also Order)
	676413	Latch Door Kit
2	3376066	Latch, Detergent Dispenser
3	3369061	Snap, Detergent Dispenser
4	3369505	Actuator Assembly
5	3369506	Wet Agent, Dispenser
6	3369448	Draw Bar, Electronic
7	3374771	Clip, Console Door Retainer
8	3368999	Spring (Draw Bar)
9	3376404	Lid Assembly
10	300106	Spring, Lid
11	3372028	Pin (Lid Hinge)
12	3371710	Screen, Vent
13	3369512	Wet-Agent Cap Assembly
14	3369155	Seal (Wet-Cap)
15	3369051	Screw (9)
16	3371569	Cover, Drip

TUB ASSEMBLY PARTS

For Model: DU920QWDB0

Black




1	3375130	Tub Assembly
2	3369078	Tub, Wheel Assembly (8)
3	3368932	Runner (2)
4	3374849	Leveler (2)
5	3370389	Screw, Shoulder
6	302819	Wheel (2)
7	343641	Screw
8	3374719	Plate, Latch
9	3374720	Screw
10	3368994	Gasket
11	3372412	Retainer, Access Panel
12	3369052	Deflector (2)
13	3375558	Heater
14	717273	Washer, Rubber (2)
15	3369073	Nut (2) (Heater Terminal)
16	3374621	Water Valve
17	304392	Screw
18	3373359	Thermostat, Hi-Limit
19	3369777	Thermostat
20	301958	Clamp
21	3376149	Shield, Thermostat
22	3374767	Insulation, Toe Panel
23	98997	Clip
25	304231	Screw
26	3382404	Sound Shield
28	3374343	Spring, Door (2)
29	3369048	Housing, Float Switch
30	3369067	Switch, Float
31	3369049	Cover, Switch Housing
32	3376397	Float & Washer Assembly
34	3368942	Toe Panel
35	3369193	Panel, Access
36	302868	Screw
37	3369414	Hose, Inlet
39	3374718	Clip, Grounding
40	3374765	Sound Shield
41	3370292	Terminal Box
42	300068	Cover Assembly, Terminal Box
43		*Access Panel
	3369527	(Almond/Black)
44	3369526	Spacer, Corrugated
45	3374728	Extension & Clip Assembly
46	3376187	Trim, Side (2)
49	3370555	Bracket, Thermostat
51	304666	Retainer, Push (2)
52	3368987	Support, Heater
53	3371578	Screw
54	3371579	Nut
55	3370307	Strain Relief
56	3369138	Screw

*Refer To Dishwasher Replacement Panel Parts List No. 675345.

PUMP AND MOTOR PARTS

For Model: DU920QWDB0

Black




1	9740982	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.
3	9741232	Screw
4	302710	Seal, Inlet Base
5	302709	Ball, Check
6	95080	"O" Ring
7	302721	Cover, Valve
8	302738	Valve Stem Kit (Includes Items 12, 13 & 22) See Note A.
9	303883	Separator Assembly (Includes Items 12, 13 & 22) See Note A.
10	3400001	Screw
11	3376402	Impeller, Wash (Includes Items 12 & 13)
12	3371152	Screw & Seal,
13	302711	Seal, Pump Outlet
14	3369478	Outlet, Pump (Includes Item 13)
15	3369482	Check Valve (Includes Item 6)
16	717000	Gasket, Pump
17	3375493	Pump & Motor Assembly (Includes Item 16)
18	302707	Bushing, Grind
19	302718	Chopper Kit (Also Order Item 30) See Note A.
20	302705	Sleeve, Drain Impeller
21	9741321	Screw
22	302704	Seal, Drain Cover
23	302723	Cover, Drain (Also Order Item 30) See Note A.
24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.
25	3376151	Base, Pump (Includes Item 24) (Also Order Item 30) See Note A.
26	3367197	Support, Pump Mounting (4)
27	3368270	Slinger (See Note A.)
28	3375480	Motor (Includes Item 27) (Also Order Item 30) See Note A.
29	3369331	Screw
30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
31	303918	Tool, Pump Centering
32	356138	Clamp, Hose
33	3368781	Hose, Drain
34	3371748	Cap, Drain
35	3374757	Shaft, Absorber
36	3374756	Weight, Absorber

NOTE A: Pump Centering Tool Required For Pump Re-Assembling--Order Item 31.

DISHRACK PARTS

For Model: DU920QWDB0

Black



1	303722	Clip
2	3368290	Support, Arm (Also Order Items 1 & 8)
3	3368300	Spray Arm, Upper (Also Order Items 1 & 8)
4	3368006	Bumper (2)
5	300848	Tower, Pressure
6	3369509	Wheel & Transport Assembly (4)
7	3375084	Dishrack, Lower (Includes Items 4 & 6)
8	3374702	Support, Lock Spray Arm
9	3369488	Silverware Basket Assembly
10	3369485	Cover, Basket
11	3374701	Stop, Track (2)
12	3369071	Track
16	3373365	Adjuster Assy.
17	300845	End Cap
18	3375108	Dishrack, Upper
19	717528	Trim, Basket
20	300086	Handle, Basket
22	3369347	Sprayarm, Lower
23	3367910	Cap, Nozzle
24	719576	Bearing, Nozzle

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
72032	Black

PAINT, PRESSURIZED SPRAY (13 oz.)

350956	Almond
285006	Superior Black
350942	Primer (White)

PAINT, TOUCH-UP (1 qt.)

978883	Almond (Uncut)
799340	Black (Uncut)

ACCESSORY PARTS

Side Panel Kits:

4317925	White
4317926	Avocado
4317927	Gold
4317929	Almond
4317930	Toast
4317931	Platinum

Door Spring Kit:

4318050	Heavy Duty
---------	------------

DISHRACK REPAIR

675576	Vinyl Touch-Up (Blue)
675677	Tine Tip Repair Kit (Blue - Enough For Two Complete Dishracks)
676453	Vinyl Touch-Up (White)
675679	Tine Tip Repair Kit (White - Enough For Two Complete Dishracks)
676455	Vinyl Touch-Up (Grey)
676458	Tine Tip Repair Kit (Grey - Enough For Two Complete Dishracks)

LITERATURE PARTS

LIT3369679	Instructions, Installation
LIT3367007	Instructions, Installation (Supplement) (Locating Your Water Supply)
LIT3373484	Energy Guide
LIT3373752	Guide, Use & Care
LIT3374754	Wiring Diagram
LIT3374766	Tech Sheet


Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

LIT00677967 Do-It Yourself, Manual

For Model: DU920QWDB0
Black

MISCELLANEOUS PARTS



1 3369816 Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)